



RumiX

Electric Crib User Guide


Suitable up to 9kg, approx. 6 months

EN 1130:2019/AC:2020

EN 16890:2017+A1:2021

For any queries, contact hello@amanababy.com





User Guide

RumiX Electric Crib



IMPORTANT!

**Read carefully and keep
for future reference.**

Welcome to Amana, where we craft each item with meticulous care to ensure your utmost trust and confidence in our products for your new arrival!

We sincerely hope that you find joy in using your Electric crib.

We kindly request you to attentively read and adhere to the provided instructions to ensure the safety and security of your little one.

Congratulations, and we extend our warmest wishes to you and your baby for the very best journey ahead.

Contents

Box Contents4

Assembling the Crib5

Product Power Supply7

Panel Functions.....8

Remote Control Instructions9

Troubleshooting10

Warning11


Care & Maintenance 12

Warranty 13

Washing Instructions 13

Box Contents

Check if the following parts are in the box / bag:




1



2



3



4



5



6



7



8




9

- | | |
|-------------------------------|----------------------|
| 1. Crib Frame (x1) | 6. Mattress (x1) |
| 2. Electronic Base (x1) | 7. Base (x1) |
| 3. Base Stand (x1) | 8. Short Screws (x8) |
| 4. Legs Left & Right (2 each) | 9. Hex Key (x1) |
| 5. Leg Brace (x2) | |

Assembling the Crib


1. Install the cross brace.

As shown in the picture (a) put the cross brace 1 between the right legs and lock it with screws. As shown in the picture (b) put the cross brace 2 between the left legs, then lock it with screws.




2. Install the legs left and right.

Insert the leg left into the leg right as shown in figure (a) and screw in.




3. Install the desktop.

As shown in the figure (a) put the desktop on the legs and lock it with screws.




4. Using the base as a table

At this stage, the base can be used as a table, or steps 5–7 can be followed to insert the cot into the base.




5. Installation of the bed frame.

As shown in the picture (a) will be the bed frame cloth cover within pipe fittings to insert; and make the shrapnel pop-up, then and close the zipper on the armrest; as shown in the picture (b). Place the bed frame on the main body, and close the zip between the bed frame and the main body.



6. Installation of the mattress.


Pull the 2 support iron wires on the bed frame to both sides as shown (a) so that the support iron wires are stuck in the plastic clips on the board. Place the subplate, then mattress in the bed as shown in (b) and spread it flat.



7. Install the bed frame.

Place the bed frame on the previously installed bracket as shown in figure (a) so that the 4 feet are aligned with the 4 holes on the tabletop. Complete the installation as shown in figure (b) then connect the 4 Velcros to enhance stability.


⚠ WARNING: Please ensure the 4 Velcros connect stable enough, otherwise there will be accident.



Product Power Supply


1. Adaptor Use.

As shown in figure (a) the adaptor plugs into the DC jack to complete the power supply. Adaptor plug can be inserted into 100–240V 50/60HZ 0.6AAC power supply, DC interface can be connected to the charging treasure power supply; adaptor output voltage is 6V, current $\leq 1000\text{MA}$.



Panel Functions

Touch panel operating instructions




- (a) Power On/Off — Press the power switch once to turn it on and the display shows the number 0, this is now switched on; press again to switch it off.
- (b) Motion button — 5 adjustment speeds.
- (c) Timer — 3 choices of setting: 8 minutes, 15 minutes or 30 minutes. The timing display will be counted down according to the time remaining in the timer and will enter standby mode when completed.
- (d) Music playback/volume button, press to play system music to start; short press to play the next music; volume +/- button to adjust the volume; long press for about 3 seconds to close the music.
- (e) Weighing button, press the display light until flashes to show the number 0000 then put the baby into the crib, the number displayed on the panel is the baby's weight.
Note: Before entering the weighing function, you need to take out the baby inside the crib and the items not carried by the cot itself.
- (f) Bluetooth Speaker — Switch the crib on and turn on the Bluetooth function of your device and search for the signal to pair PT-BABY; you can also adjust the volume of the rocking bed through the device used to pair.

Remote Control Instructions

Button cell batteries are included in the remote control.

Remove the insulating plastic sheet before switching on the power.



- | | |
|-------------------------------|---------------------------------|
| 1. Power on key | 7. Next one |
| 2. Reducing the rocking level | 8. Switch in/out music |
| 3. Increase the rocking level | 9. Play/Pause |
| 4. The volume increases | 10. Cycle time(8/15/30 minutes) |
| 5. The volume reduction | 11. Weight |
| 6. Last one | |

Troubleshooting

Issues	Resolution
Not powered on	Checking the power supply
Not the original power supply	Use the original power supply
Battery not installed or positive and negative battery wrong terminals	Install batteries with positive and negative terminals as indicated
The battery is low	Replace with new batteries
Stop rocker is not unlocked	Disengage the rocker lock
Rocker/Cradle is blocked	There should be no obstruction around the moving parts
The power switch has not been turned on and the speed control button has not been activated	Turn on the power and activate the speed button according to the instructions
The timer stops automatically when it is set	Restart the speed button
The function buttons do not work during normal use	Unplug and restart
The baby is placed in a skewed position	Place the baby in the centre of the cot
Parts are installed incorrectly, causing jamming	Reinstall the crib according to the instructions
The load seriously exceeds the maximum load capacity	Do not exceed the maximum load capacity of the product
If there is a serious noise, or the light does not turn on, or the horn does not sound, the system will not work	Contact After Sales
When assembling according to the instructions, there are missing parts or damaged parts that cannot be assembled efficiently	Contact After Sales

Warning

 **WARNING:** Do not leave unattended children alone in the product.

 **WARNING:** Suitable for ages: 0–6months(Baby bassinet); 12months+(desk).

 **WARNING:** Do not use this product without reading the instructions for use first.

 **WARNING:** Do not lift or move this product when the child is in it.

 **WARNING:** Stop using the product as soon as the child can sit or kneel or pull itself up.

 **WARNING:** The product should be placed on a horizontal floor.

 **WARNING:** Placing additional items in the product may cause suffocation.

 **WARNING:** Do not place the product close to another product, which could present a danger of suffocation or strangulation, e.g. strings, blind/curtain cords, etc.

 **WARNING:** Young children should not be allowed to play unsupervised in the vicinity of the crib.

 **WARNING:** Do not use more than one mattress in the product.

 **WARNING:** Only use the mattress sold with this crib, do not add a second mattress on this one,– suffocation hazards.

 **WARNING:** When this product is connected to a music player, make sure the volume of the player is set to the bass position.

 **WARNING:** Do not use this product if any parts are damaged or missing. Contact Amana for replacement parts and instructional literature if needed. DO NOT substitute parts.

 **WARNING:** Be aware of the risk of open fire and other sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the crib.

 **WARNING:** Ensure that you use a safe system configuration when using the product.

 **WARNING:** All assembly fittings should always be tightened properly and that care should be taken that no screws are loose, because a child could trap parts of the body or clothing (e.g. strings, necklaces, ribbons for babies' dummies, etc.), which would pose a risk of strangulation.

Care & Maintenance

- All assembly fittings that can be should always be tightened properly and that care should be taken that no screws are loose, because a child could trap parts of the body or clothing (e.g. strings, necklaces, ribbons for babies' dummies, etc.), which would pose a risk of strangulation.
- To prolong the life of your crib, keep it clean and do not leave in the direct sunlight for extended periods of time.
- Do not use abrasive cleaners. Do not soak in water.
- Removable fabric covers and trims may be cleaned using warm water with a house-hold soap or a mild detergent. Allow it to dry fully, preferably away from direct sunlight.
- Always store your product in a clean dry place.
- Do not allow this product to come in contact with sand or salt water, sand causes corrosion and salt water the formation of rust.
- Do not dry clean or use bleach.
- Do not machine wash, tumble or spin dry. Fabric and frame may be cleaned using a damp sponge with soap or mild detergent. The mattress can be washed by hand (see washing label). Allow it to dry completely before folding or storing it away.
- In some climates the parts may be affected by mould and mildew. To help prevent this occurring, do not fold or store the product if it is damp or wet.
- Always store the product in a well ventilated area.
- Always check parts regularly for tightness of screws, nuts and other fasteners, tighten if required. To maintain the safety of your crib, seek prompt repairs for bent, torn, worn or broken parts.
- Use only parts and accessories approved by the supplier.

Washing Instructions

⚠ WARNING: This is a mattress, do not add a second mattress, suffocation hazards.

Outer fabric: 100% Polyester



Warranty

- All our products are made from the finest quality materials and are manufactured under the strictest quality controls.
- We guarantee all our products or parts thereof, for a period of one (1) year from the date of purchase against manufacturing defects.
- For warranty purposes we will require proof of purchase. We recommend that the receipt for your product is kept in a safe place.
- This in no way affects your statutory rights.
- For any claim related with the warranty of this product we suggest to contact your retailer who will advise you how to proceed.



 amanababy.com

hello@amanababy.com
Imported by Millsons of London Ltd. EC1V 2NX
Made in China